

WORKSHOP MANUAL

KB

SECTION 07D

MSG FIVE-SPEED TRANSMISSION



ISUZU MOTORS LIMITED



CONTENTS	PAGE
General description	07D— 1
Specifications	07D— 3
Fixing torque	07D— 4
Transmission assembly	07D— 5
Removal and installation	07D— 5
Disassembly	07D— 8
Inspection and repair	07D—15
Reassembly	07D—18
Transmission control	07D—31
Disassembly	07D—31
Inspection and repair	07D—32
Reassembly	07D—33
Trouble shooting	07D—35

1. The first part of the document discusses the importance of maintaining accurate records of all transactions. This is essential for ensuring the integrity of the financial statements and for providing a clear audit trail.

2. The second part of the document outlines the various methods used to collect and analyze data. These methods include direct observation, interviews, and the use of specialized software tools.

3. The third part of the document describes the results of the data collection and analysis. It shows that there are significant differences between the reported and actual values in several key areas.



4. The fourth part of the document discusses the reasons for these differences and the steps that need to be taken to correct them. This includes improving internal controls and enhancing the accuracy of data collection.

5. The fifth part of the document provides a summary of the findings and recommendations. It emphasizes the need for ongoing monitoring and improvement of the financial reporting process.




GENERAL DESCRIPTION


GEAR SHIFT DIAGRAM



ARRANGEMENT OF GEAR SHIFT CONTROL PARTS



TRANSMISSION CONTROL (REMOTE CONTROL TYPE)




SPECIFICATIONS

Models	KB29	KB21, 23, 26, 28 KBD21, 22, 26, 27	
Transmission Fluid	Engine oil SAE5W-30 Approx. 1.55 liters (0.41 US gallon)		
Type			
Capacity			
Gear shifting	Floor mounted, or remote control type		
Gear Ratios	5C	5L	5K
1st	3.431	4.697	4.122
2nd	1.969	2.841	2.493
3rd	1.364	1.629	1.504
4th	1.000	1.000	1.000
5th	0.855	0.898	0.855
Reverse	3.402	4.277	3.753
Speedometer gear ratio	6/19 (only Australia)	5/17 (payload 1 ton) or 6/19 (payload 0.5 ton)	

FIXING TORQUE


kg·m(ft.lbs.)



TRANSMISSION ASSEMBLY




REMOVAL AND INSTALLATION

**Removal Steps**

- ▲ 1. Plug ; magnet, oil drain
- 2. Gear shift lever assembly
- 3. Starter motor
- 4. Speedometer cable
- 5. Center bearing
- 6. Propeller shaft
- 7. Clutch cable
- 8. Flywheel stone guard
- ▲ 9. Frame bracket to transmission rear mount bolts and nuts
- ▲ 10. Transmission to engine attaching bolts and transmission assembly

Installation steps


- ▲ 10. Transmission to engine attaching bolts and transmission assembly
- ▲ 9. Frame bracket to transmission rear mount bolts and nuts
- 8. Flywheel stone guard
- 7. Clutch cable
- ▲ 6. Propeller shaft
- 5. Center bearing
- 4. Speedometer cable
- 3. Starter motor
- 2. Gear shift lever assembly
- ▲ 1. Plug ; magnet, oil drain




Important operations — Removal

1. Plug ; magnet, oil drain

Drain transmission case and disconnect negative (-) side cable from the battery at terminal.




9. Remove the bracket holding up the rear end of the transmission



10. Transmission to engine attaching bolts and transmission assembly.

Position a jack under the transmission case, remove engine rear mounting nuts, lower the transmission case slightly, then remove bolts attaching quadrant box cover to transmission case.


Disconnect back-up light switch harness, neutral switch harness and other harnesses at connector.



When removing transmission, turn the transmission case 90 degrees clock wise for easier removal.




Important operations – Installation




10. Transmission to engine attaching bolts and transmission assembly

Position the transmission assembly with the speedometer cable mounting surface turned downward and slide the assembly forward, guiding the gear shaft into pilot bearing.



9. Install the bracket holding up the rear end of the transmission




6. Propeller shaft

Install the bolts from the extension shaft side.



Torque	kg·m(ft.lbs.)	3-3.4 (22-25)
--------	---------------	---------------



1. Plug ; magnet, oil drain


Install and tighten drain plug to specification, remove the filler plug and fill the transmission case with transmission fluid to the specified level.

Install and tighten the filler plug to the specified torque (the same torque should be used for tightening drain plug and filler plug).




DISASSEMBLY

MAJOR COMPONENT



Disassembly steps

- | | |
|-------------------------------------|--|
| 1. Quadrant box | 8. Back-up light switch |
| 2. Shift block assembly | 9. Rear cover |
| 3. Withdraw lever | 10. Oil seal |
| 4. Front cover ; oil seal | 11. Main shaft assembly, cluster gear assembly and top gear shaft assembly |
| ▲ 5. Belleville spring | |
| 6. Snap ring | |
| 7. Speedometer driven gear assembly | |




Important operation

5. Belleville spring

Remove the bearing retainer and the retainer, gasket and belleville spring.


MINOR COMPONENTS

MAIN SHAFT ASSEMBLY, CLUSTER GEAR ASSEMBLY AND TOP GEAR ASSEMBLY




Disassembly steps

1. Plate ; detent spring
2. Spring ; detent ball
3. Ball ; detent, gear shift
- ▲ 4. Shaft ; arm, gear shift, reverse-5th
5. Fork ; reverse-5th, shift
- ▲ 6. Shaft ; gear shift low-2nd
- ▲ 7. Shaft ; gear shift, top-3rd
8. Fork ; top-3rd, shift
9. Fork ; low-2nd, shift
10. Pin and plug ; inter lock
11. Ring ; snap, speed drive gear
12. Gear ; speed, drive
13. Key ; feather, speed drive gear
14. Spacer ; bearing, drive gear
15. Bearing ; ball, main shaft end
16. Ring ; snap, ball bearing
17. Ring ; snap, thrust ring
18. Retaning ring
19. Thrust ring ; 5th gear
20. Washer ; thrust, 5th
21. Nut ; self lock, counter
22. Washer ; plane, counter 5th gear
- ▲ 23. Bearing ; ball, counter end
- ▲ 24. Gear ; counter, 5th
25. Gear assembly ; 5th with synchronizer cone
26. Bearing ; needle, 5th
27. Ring ; block, 5th
- ▲ 28. Nut ; main shaft
29. Washer ; lock, main shaft
30. Synchronizer assembly ; reverse-5th
31. Gear ; reverse, main shaft
32. Bearing ; needle, low
33. Nut ; self lock, counter
34. Washer ; thrust, reverse idle, rear
35. Gear ; reverse idle, with bushing
36. Washer ; thrust, reverse idle, front
37. Plate ; intermediate
38. Ring ; snap, bearing to top shaft
39. Shaft ; top gear, with synchronizer cone
- ▲ 40. Bearing ; ball, top gear shaft
41. Bearing ; needle, main shaft
42. Ring ; block, top-3rd
43. Ring ; snap, main shaft
44. Synchronizer assembly ; top-3rd
45. Ring ; block, top-3rd
46. Gear assembly ; 3rd with synchronizer cone
47. Bearing ; needle, 2nd, 3rd
- ▲ 48. Gear assembly ; low-2nd
49. Washer ; thrust, low
- ▲ 50. Bearing ; radial ball, main shaft
51. Coller ; needle bearing, low
52. Washer ; thrust, low
53. Gear assembly ; low, with synchronizer cone
54. Bearing ; needle, low
55. Coller ; needle bearing, low
56. Ring ; block, low-2nd
57. Synchronizer assembly ; low-2nd
58. Ring ; block, low-2nd
59. Gear assembly ; 2nd with synchronizer cone
60. Bearing ; needle, 2nd, 3rd
- ▲ 61. Gear ; counter reverse
- ▲ 62. Bearing ; angular ball, cluster
63. Gear ; cluster
64. Ring ; snap, cluster gear
65. Bearing ; ball, counter front
66. Ring ; snap, cluster gear
67. Ring ; snap, main shaft
68. Shaft ; reverse idle

**Important operations****4. Shift ; arm, gear reverse-5th**

Spring pin remover : 9-8529-2201-0




6. Shift ; arm, gear shift, low-2nd

7. Shift ; arm, gear shift, top-3rd

When removing the spring, hold a round bar against the end of the shift rod for protection against damage.


Spring pin remover : 9-8529-2201-0



23. Bearing ; ball, counter end

24. Gear ; counter, 5th


Remover : 5-8840-0013-0
(J-22888)



28. Nut ; main shaft


(1) Engage top/3rd synchronizer with the third gear and Low/2nd side synchronizer with the Low gear, then attach Tool to the main shaft and the countergear.

Holding fixture : 5-8840-2001-0
(J-29768)



(2) This operation is necessary to prevent turning of the shaft when removing main shaft rear and countershaft reverse gear lock nut.


Wrench : 5-8521-9014-0
(J-33441)



40. Bearing ; ball, top gear shaft

Use a bench press


Bearing remover : 5-8840-0015-0
(J-22912-01)



48. Gear assembly ; low-2nd

Remove the parts (47 through 58) from the main shaft together using special tool.


Bearing remover : 5-8840-0015-0
(J-22912-01)



50. Bearing ; radial ball, main shaft

Use a bench press.

Bearing remover : 5-8840-0015-0
(J-22912-01)




61. Gear ; counter reverse

62. Bearing ; angular ball, cluster

Use a bench press for removal.

Bearing remover : 5-8840-0015-0
(J-22912-01)

QUADRANT BOX ASSEMBLY




Disassembly steps

- | | |
|--------------------------|--------------------------|
| 1. Select lever bolt | 7. Internal select lever |
| 2. External select lever | 8. Internal shift lever |
| 3. O-ring | 9. Sleeve |
| 4. Bushing | 10. Spring |
| 5. External shift lever | 11. Spring seat |
| 6. Oil seal | |




INSPECTION AND REPAIR

Make necessary correction or parts replacement if wear, damage or any other abnormal conditions are found through inspection.




Shift arm thickness

		mm(in.)
	Standard	Limit
Low/2nd	7.8-7.9 (0.307-0.311)	7.0 (0.276)
3rd/4th	7.1-7.2 (0.280-0.283)	6.5 (0.256)
Rev./5th	6.8-6.9 (0.268-0.272)	6.3 (0.248)




Free length of detent springs

	mm(in.)	
	Standard	Limit
	27.7 (1.091)	24.7 (0.973)




Spring tension

		kg(lb.)
Set length	Standard	Limit
22.1 mm (0.87 in.)	6.3-6.7 (13.9-14.8)	5.7 (12.6)




Clearance between blocker ring and gear

mm(in.)		
	Standard	Limit
	1.5 (0.059)	0.8 (0.031)
	Standard	Limit
Low/2nd	1.7 (0.067)	0.8 (0.032)
3rd/5th	1.5 (0.059)	0.8 (0.032)
Top	1.3 (0.051)	0.8 (0.032)




Clearance between blocker ring and inserts

mm(in.)		
	Standard	Limit
	3.51 – 3.79 (0.138 – 0.149)	4.0 (0.157)




Clearance between clutch hub and inserts

mm(in.)		
	Standard	Limit
	0.01 – 0.19 (0.0004 – 0.0075)	0.3 (0.012)




Main shaft run-out

	Limit	mm(in.)
		0.03 (0.001)




Gear inside diameter

	mm(in.)	
	Standard	Limit
Low, rev.	45.0-45.01 (1.772-1.77339)	45.1 (1.776)
2nd, 3rd	41.0-41.01 (1.614-1.61579)	41.1 (1.618)
5th (C223NA)	32.03-32.04 (1.261-1.26141)	32.1 (1.264)
5th 4ZD1	34.03-34.04 (1.334-1.340)	34.1 (1.343)




Clearance between bushing and idler gear shaft

		mm(in.)
Standard	Limit	
0.041-0.074 (0.0016-0.0292)	0.15 (0.006)	



Play in splines

	mm(in.)	
	Standard	Limit
Top, 3rd	0-0.19 (0-0.0075)	0.20 (0.0079)
Low, 2nd	0-0.19 (0-0.0075)	0.20 (0.0079)



Play in ball bearings


Limit	mm(in.)	
		0.2 (0.0079)



REASSEMBLY


MINOR COMPONENTS

QUADRANT BOX ASSEMBLY



Reassembly steps

- | | |
|---------------------------|---------------------------|
| 1. Spring seat | 7. Internal select lever |
| 2. Spring | 8. Bushing |
| 3. Sleeve | 9. O-ring |
| 4. Internal shift lever | 10. External select lever |
| 5. Oil seal | 11. Select lever bolt |
| ▲ 6. External shift lever | |




Important operation

- 6. External shift lever


MINOR COMPONENTS

MAIN SHAFT ASSEMBLY, CLUSTER GEAR ASSEMBLY AND TOP GEAR ASSEMBLY



Reassembly steps

1. Shaft ; main
2. Bearing ; needle, 2nd, 3rd
- ▲ 3. Gear assembly ; 2nd with
synchronizer cone
4. Ring ; block, low-2nd
- ▲ 5. Synchronizer assembly ; low-2nd
6. Ring ; block, low-2nd
- ▲ 7. Coller ; needle bearing, low
8. Bearing ; needle, low
9. Gear assembly ; low with
synchronizer cone
- ▲ 10. Washer ; thrust, low
- ▲ 11. Bearing ; radial ball, main shaft
- ▲ 12. Washer ; thrust, reverse
- ▲ 13. Coller ; needle bearing, reverse
14. Bearing ; needle, 2nd, 3rd
15. Gear assembly ; 3rd with
synchronizer cone
16. Ring ; block, top-3rd
- ▲ 17. Synchronizer assembly ; top-3rd
- ▲ 18. Ring ; snap, main shaft
19. Ring ; block, top-3rd
20. Bearing ; needle, main shaft
- ▲ 21. Bearing ; ball, top gear shaft
22. Ring ; snap, bearing to top gear shaft
23. Shaft ; top gear, with synchronizer
cone
24. Bearing ; ball, counter front
25. Ring snap, cluster gear
26. Gear ; cluster
- ▲ 27. Bearing ; angular ball, cluster
28. Gear ; counter reverse
- ▲ 29. Shaft ; reverse idle
30. Ring ; snap, main shaft
31. Ring ; snap, cluster gear
- ▲ 32. Plate ; intermediate
33. Washer ; thrust, reverse idle, front
34. Gear ; reverse idle, with busing
35. Washer ; thrust, reverse idle, rear
- ▲ 36. Nut ; self lock, counter
37. Bearing ; needle, low
38. Gear ; reverse, main shaft
- ▲ 39. Synchronizer assembly ; reverse-5th
40. Washer ; lock, main shaft
- ▲ 41. Nut ; main shaft
42. Ring ; block, 5th
43. Gear assembly ; 5th with
synchronizer cone
44. Bearing ; needle, 5th
- ▲ 45. Washer ; thrust, 5th
46. Thrust ring ; 5th gear
- ▲ 47. Ring ; snap, thrust ring
48. Retaining ring
49. Ring ; snap, ball bearing
50. Bearing ; ball, main shaft end
51. Spacer ; bearing, drive gear
52. Gear ; speed drive
53. Key ; feather, speed drive gear
54. Ring ; snap, speed drive gear
55. Gear ; counter, 5th
56. Bearing ; ball, counter end
57. Washer ; plane, counter 5th gear
- ▲ 58. Nut ; self lock, counter
59. Pin and plug ; inter lock
60. Fork ; low-2nd, shift
- ▲ 61. Shaft ; arm, gear shift, top-3rd
62. Fork ; top-3rd, shift
- ▲ 63. Shaft ; arm, gear shift, low-2nd
64. Fork ; reverse-5th, shift
- ▲ 65. Shaft ; arm, gear shift, reverse-5th
66. Ball ; detent, gear shift
- ▲ 67. Spring ; detent ball
- ▲ 68. Plate ; detent spring




Important operations





3. Gear assembly ; 2nd with synchronizer cone

The taper cone face of the second gear should be turned to the low gear side (rearward).



5. Synchronizer assembly ; low-2nd


(1) When reassembling the synchronizer assembly, the side of the clutch hub with the ② oil groove must face the heavy chamfer of the sleeve.



(2) Check that the inserts fit properly into the insert grooves in the blocker ring and that the insert spring is aligned with the insert keys as shown in this figure. Then check that the clutch hub and sleeve slide smoothly.

(3) Install the synchronizer assembly on the shaft, so that face of sleeve with light chamfer on the outer edge is turned to the front of transmission.

- ③ ; Insert key
- ④ ; Insert spring
- ⑤ ; Clutch hub




7. Collar ; needle bearing, low

Use a bench press.

Installer : 5-8840-0178-0
(J-33851)






10. Washer ; thrust, low

Install the thrust washer, so that the side with oil groove is turned forward.


① ; Oil groove



11. Bearing ; radial ball, main shaft

Set the main shaft ball bearing to the separator, so that the face with the snap ring groove is turned to the front of transmission, then install the bearing on the shaft using a bench press.


① ; Snap ring groove



12. Washer ; thrust, reverse

Install the thrust washer, so that the side with oil groove is turned forward.


① ; Oil groove



13. Collar ; needle bearing, reverse


Use a bench press.

Installer : 5-8840-0178-0
(J-33851)



17. Synchronizer assembly ; top-3rd

When reassembling the synchronizer assembly, the side of the hub with the higher boss must face the light chamfer of the sleeve.




18. Ring ; snap, main shaft

Clearance between top/3rd clutch hub and snap ring.

Standard	mm(in.)	0-0.05 (0-0.0019)
----------	---------	-------------------

Thicknesses of available snap rings:


Thickness		Identification mark
Millimeters	Inches	
1.50	0.059	1
1.55	0.061	2
1.60	0.063	3
1.65	0.065	4



21. Bearing ; ball, top gear shaft

Install the top gear shaft ball bearing, so that the side with snap ring groove is turned to front.

① ; Snap ring groove



27. Bearing ; angular ball, cluster


Install the cluster gear rear bearing, so that the side with snap ring groove is turned rearward.

① ; Snap groove



29. Shaft ; reverse idle

Torque	kg-m(ft.lbs.)	1.8-2.2 (13-16)
--------	---------------	-----------------




32. Plate ; intermadiate


Mesh the countergear with the mainshaft assembly and attach Tool to the mainshaft and the countergear.

Place Tool with the mainshaft and countergear assembled in a vise, then install the intermediate plate.

Holding fixture : 5-8840-2001-0
(J-29768)




Engage the Top/3rd and Low/2nd synchronizers with the 3rd and Low gears, then attach and tighten the lock nuts to the specified torque as follows.



36. Nut ; self locking, counter

Torque	kg·m(ft.lbs.)	10-12 (72-87)
--------	---------------	---------------


Discard the used nut and install new one at reassembly.



39. Synchronizer assembly ; reverse-5th

When reassembling the synchronizer assembly, the side of the clutch hub with higher boss must face the heavy chamfer of the sleeve. The shorter shoulder side of the insert should be on the same side.

- ① ; Shorter shoulder side
- ② ; Heavy chamfering




41. Nut ; main shaft

Lock the nut with lock washer after tightening it to the specified torque.

"Be absolutely certain to bend the lock washer pawl in two places."


Wrench : 5-8521-9014-0
(J-33441)

Torque	kg·m(ft.lbs.)	12-14 (87-101)
--------	---------------	----------------



45. Washer ; thrust, 5th

Install the lock ball and thrust washer on the mainshaft using a snap ring.




Clearance between 5th gear and thrust washer.

Standard	mm(in.)	0.10-0.30 (0.004-0.012)
----------	---------	-------------------------

Thicknesses of thrust washers available.

(mm)	7.8,	7.9,	8.0,	8.1,	8.2,	8.3
(in.)	0.307,	0.311,	0.315,	0.319,	0.323,	0.327




47. Ring ; snap, thrust ring

The opening of the snap ring should be positioned at right angle to opening of the thrust ring.

58. Nut



Torque	kg·m(ft.lbs.)	10-12 (72-87)
--------	---------------	---------------



61. Shaft ; arm, gear shift, top-3rd


63. Shaft ; arm, gear shaft, low-2nd

65. Shaft ; arm, gear shift, reverse-5th

When installing spring pin, hold a round bar against lower face of shift rod end to protect it against damage.

Discard used spring pin and install a new one at reassembly.


Spring pin installer : 9-8529-2201-0



67. Spring ; detent ball

The detent spring for Rev./5th is shorter in length when compared with those for Low/2nd and Top/4th.


mm(in.)	
Spring length	27.7 (1.091)



68. Plate ; detent spring


Torque	kg·m(ft.lbs.)	1.8—2.2 (13—16)
--------	---------------	-----------------

MAJOR COMPONENTS



Reassembly steps

- | | |
|--|----------------------------|
| ▲ 1. Oil seal | 6. Snap ring |
| ▲ 2. Mainshaft assembly, cluster gear assembly and top gear shaft assembly | ▲ 7. Belleville spring |
| ▲ 3. Rear cover | ▲ 8. Front cover, oil seal |
| 4. Back-up light switch | ▲ 9. Bolt; front cover |
| ▲ 5. Speedometer driven gear assembly | 10. Withdraw lever |
| | ▲ 11. Shift block assembly |
| | 12. Quadrant box assembly |



Important operations



1. Oil seal

Oil seal installer : 5-85220-026-0
(J-26508)



2. Main shaft assembly, cluster gear assembly, top gear shaft assembly.



- (1) Apply a small amount of oil or grease to the top gear shaft ball bearing joining surface of the transmission case and shift rods to facilitate smooth installation.
- (2) When the intermediate plate assembly is installed, pull out the top gear shaft until the ball bearing snap ring groove is projected beyond the front cover fitting face of the transmission case.
- (3) Do not apply shock load to the main shaft.



3. Rear cover


Install the rear cover with gasket on the transmission case by aligning the dowel pin.



Torque	kg·m(ft.lbs.)	3.8—4.2 (27—30)
--------	---------------	-----------------

5. Speedometer drive gear, oil seal, bushing O-ring


Key groove is contoured to receive feather key.



7. Belleville spring

The belleville spring should be so installed that its dished face is turned to the bearing outer race.

- ① : Transmission case
- ② : Front cover
- ③ : Belleville spring



8. Front cover, oil seal

Install the front cover oil seal.
Oil seal installer : 5-8840-0026-0
(J-26540)



9. Bolt; front cover

Torque	kg·m(ft.lbs.)	1.8—2.2 (13—16)
--------	---------------	-----------------

Apply adhesive (Permatex No. 2 or equivalent) to the threaded portion of the through bolt on the left lower side of the transmission case (as viewed from front side of the case) before installation.



11. Shift block assembly


Apply grease to the inner face of the shift block.
Check that the hook on the shift fork is fitted to the support properly.

TRANSMISSION CONTROL



DISASSEMBLY


GEAR CONTROL ASSEMBLY



Disassembly steps

1. Select rod ; rear
2. Shift rod ; rear
3. Shift rod ; front
4. Select rod ; front
5. Relay lever and bracket assembly

CHANGE LEVER ASSEMBLY



Disassembly steps

- | | |
|--------------------------|-------------------|
| 1. Shift lever | 8. Snap ring |
| 2. Lower support bracket | 9. Seat |
| 3. Pivot pin | 10. Shaft |
| 4. Select lever | 11. Spring |
| 5. Pin | 12. Control shaft |
| 6. Gear shift lever | 13. Return spring |
| 7. Dust cover | 14. Washer |




INSPECTION AND REPAIR

Make necessary correction or parts replacement if wear, damage or any other abnormal conditions are found through inspection.



REASSEMBLY


CHANGE LEVER ASSEMBLY



Reassembly steps

- | | |
|------------------|---------------------------|
| 1. Washer | 8. Dust cover |
| 2. Return spring | 9. Gear shift lever |
| 3. Control shaft | 10. Pin |
| 4. Spring | 11. Select lever |
| 5. Shaft | 12. Pivot pin |
| 6. Seat | 13. Lower support bracket |
| 7. Snap ring | 14. Shift lever |

GEAR CONTROL ASSEMBLY



Reassembly steps

- | | |
|-------------------------------------|----------------------|
| 1. Relay lever and bracket assembly | 4. Shift rod ; rear |
| 2. Select rod ; front | 5. Select rod ; rear |
| 3. Shift rod ; front | |

TROUBLE SHOOTING

Condition	Possible Cause	Correction
Hard Shifting	<ol style="list-style-type: none"> 1. Clutch 2. Synchronizers worn or broken. 3. Shift shafts or forks worn. 	<ol style="list-style-type: none"> 1. Adjustment 2. Replace 3. Replace
Slips out of Gear	<ol style="list-style-type: none"> 1. Shift shafts worn. 2. Bearings worn. 3. Drive gear retainer broken or loose. 4. Excessive play in synchronizers. 	<ol style="list-style-type: none"> 1. Replace 2. Replace as necessary. 3. Tighten or replace retainer. 4. Replace
Noisy in All Gears	<ol style="list-style-type: none"> 1. Insufficient lubricant. 2. Worn countergear bearings. 3. Worn or damaged drive gear and countergear. 4. Damaged drive gear or main shaft 5. Worn or damaged countergear. 	<ol style="list-style-type: none"> 1. Fill to correct level. 2. Replace countergear bearings and shaft. 3. Replace worn or damaged gears. 4. Replace damaged bearings or drive gear. 5. Replace countergear.
Noisy in Neutral	<ol style="list-style-type: none"> 1. Damaged drive gear bearing. 2. Damaged or loose pilot bearing. 3. Worn or damaged countergear. 4. Worn countergear bearings. 	<ol style="list-style-type: none"> 1. Replace damaged bearing. 2. Replace pilot bearing. 3. Replace countergear. 4. Replace countergear bearings and shaft.
Noisy in Reverse	<ol style="list-style-type: none"> 1. Worn or damaged reverse idler gear or idler bushing. 2. Worn or damaged reverse gear. 3. Damaged or worn countergear. 	<ol style="list-style-type: none"> 1. Replace reverse idler gear assembly. 2. Replace reverse gear. 3. Replace countergear assembly.
Leaks lubricant	<ol style="list-style-type: none"> 1. Excessive amount of lubricant in transmission. 2. Loose or broken drive gear bearing retainer. 3. Drive gear bearing retainer gasket damaged. 4. Center support gaskets either side. 5. Rear extension seal. 6. Speedo driven gear 	<ol style="list-style-type: none"> 1. Drain to correct level. 2. Tighten or replace retainer. 3. Replace gasket. 4. Replace gaskets. 5. Replace. 6. Replace O ring seal

KBT5-WE-65G

You are requested to order this manual using the manual number that is shown above.

This manual is applicable for vehicles in all countries except USA and Canada.

Copyright reserved for this manual may not be reproduced or copied, in whole or in part, without the written consent of ISUZU MOTORS LIMITED.

Issued by

ISUZU MOTORS LIMITED

OVERSEAS SERVICE DEPARTMENT

Tokyo, Japan

First edition Aug., 1985

6508-01K-8





